



## Motion Computing Software Release Note

Name	<b>C5t &amp; F5t BIOS A05</b>
File Name	<b>CF5t_A05_BIOS.zip</b>
Release Date	April 11, 2013
This Version	A05
Replaces Version	All previous versions
Intended Users	<b>Motion Computing C5t and F5t users</b>
Intended Product	Motion Computing C5t and F5t Tablet PCs only
File Size	2 MB
Supported Operating System	Windows 8 (32-bit/64-bit) Windows 7 (32-bit/64-bit) Windows XP (32-bit)

### Fixes in this Release

- LCD brightness settings had been adjusted to conserve power.
- Cannot enter BIOS setup after S4 resume process is canceled.

### Installation and Configuration Instructions

**Note:** Ensure the tablet is using AC power before installing the BIOS update.

**To install the C5t & F5t BIOS A05 update, perform the following steps:**

1. Download the BIOS update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Double-click installer (.exe file) and follow the prompts.
4. The update process may take some time. Do not manually power off the tablet during the update.
5. The tablet will automatically shut down after installing the BIOS.

### Licensing

Refer to your applicable end user licensing agreement for usage terms.